

# **Roadway Calculations in AGi32**

# Introduction

There are two techniques used to perform roadway specific calculations in AGi32: the *Roadway Optimizer* and the *Calculation Points – Roadway* command<sup>1</sup>. The calculation methodology employed is similar, but usage patterns for each function may be completely different. *Roadway Optimizer* can predict pole spacing for a variety of typical roadway configurations with a few clicks and produce instant presentation quality output. The *Calculation Points – Roadway* command on the other hand is used to place roadway calculation grids in AGi32's Model Mode to be integrated with CAD backgrounds and possibly luminaire locations covering a project boundary of larger scope.

AGi32's roadway capabilities are easily elevated to a level beyond the expectations of published standards. A discussion of the use of reflective surfaces (objects) expands analysis techniques to consider shadow casting and reflecting environments and opens the world of visualization to roadway lighting professionals.

Finally, a brief description of the new research oriented *Roadway Standard Configuration Tool* is included. The configuration tool allows the assumptions inherent in a roadway standard to be adjusted and customized in order that our industry may develop a deeper understanding of the calculations being employed and their correlation to roadway design practice.

AGi32 supports all popular international standards: North American IES-RP-8-2000, British BSEN 13201-3.2003, European CIE-140-2000, Australian AS1158.2-2005 and New Zealand NZ1158.2-2005.

Roadway Optimizer	page 2
Calculation Points – Roadway command	page 5
Roadway Calculations in 3-dimensional Environments	page 7
Roadway Standard Configuration Tool	page 9

<sup>&</sup>lt;sup>1</sup> Roadway specific calculations refers to the calculation of pavement luminance and related quantities

# **Roadway Optimizer**

The Roadway Optimizer is essentially a complete roadway design program in its own right. The Roadway Optimizer has the ability to predict pole spacing for a variety of road configurations while optimizing on multiple calculation criteria simultaneously. Each calculation iterates until all requested criteria are either met or, if not possible, program tolerances are reached. Detailed output of all calculated metrics is displayed immediately, bypassing AGi32's main program area.

#### Steps to use AGi32's Roadway Optimizer

Each step references Figure 1 below

- 1. Select a Roadway Standard (Ex: IES RP-8-2000)
- 2. Select roadway pavement characteristics, i.e. an R-table. AGi32 supports many international R-tables and you can add additional tables easily if available
- 3. Select Roadway Layout specifics:
  - a. Layouts include: 1-row, 2-rows, 4-rows, opposite, staggered, near side, far side, with or without median
  - b. Number of lanes: 2-direction calculations such as CIE can specify number of lanes in both directions
  - c. Roadway width in direction of travel
  - d. Median width
  - e. Drivers side of roadway (left or right)
  - f. Calculation area (top or bottom)
- 4. Specify Luminaire Layout: different luminaires, setbacks, mounting heights, aiming angles can be used for each row.
- 5. Select Optimization Criteria (as many as needed):
  - a. Max Lv Ratio
  - b. Avg/Min Illuminance ratio
  - c. Avg/Min Luminance ratio
  - d. Minimum Illuminance
  - e. Minimum Luminance
  - f. Average Illuminance
  - g. Average Luminance
- 6. Click the Calculate button
- 7. All calculations required by the selected standard are performed and statistics shown. If the selected Optimization Criteria have been met or exceeded, the headings are shown in Bold in the statistical window. If they were not achieved, the results are shown in red
- 8. Each point-by-point grid can be reviewed in the graphics window by selecting it in the statistical list (arrow is shown for currently viewed metric)
- 9. Pole spacing is computed to meet the selected Optimization Criteria



Figure 1 – The Roadway Optimizer

#### Refine the pole spacing manually if desired (Figure 2):

- 10. Select the "Calculate Based on Set Spacing" setting
- 11. Manually enter pole spacing for each row
- 12. Click the Calculate button

Configure      Configu	
Layout: C1 C2 Comparison Layout: C1 C2 Comparison Layout: C1 C2 C2 C4 C5 Description Sample layout #1 CGeneral Roadway Standard IES RP-8-2000 R1-table R3 (Stightly Specular), Q0=0.07 Actual Q0 Value 0.07 Configure	X Close
Layout: C 1 C 2 C 4 C 5 Description Sample layout #1 Configure General Roadway Standard IES RP-8-2000 R-Table R3 (Stightly Specular), Q0=0.07 Actual Q0 Value [0.07 Roadway Standard IES RP-8-2000 R-Table R3 (Stightly Specular), Q0=0.07 Roadway Standard IES RP-8-2000 R-Table R3 (Stightly Specular), Q0=0.07 Roadway Standard IES RP-8-2000 R-Table R3 (Stightly Specular), Q0=0.07 Roadway Standard IES RP-8-2000 R-Table R3 (Stightly Specular), Q0=0.07 Roadway Standard IES RP-8-2000 R-Table R3 (Stightly Specular), Q0=0.07 R-Table R3 (Stightly Specular), Q0=0.07 Roadway Standard IES RP-8-2000 R-Table R3 (Stightly Specular), Q0=0.07 R-Table R3 (S	
Tube       Twe Rows, Staggered, With Medan, 2R_STG_w/M       Roodway, Widh 36       Medan Widh 10         Number Of Lanes:       In Diposite Direction 0       Dirver's Side Of Roadway. C Lett © Right       Minimum Luminance         Calculation Area:       © Botom C Top       Top       Provide Dirver's Side Of Roadway. C Lett © Right       Provide Dirver's Side Of Roadway. C Lett © Right         Row 4:       Image: Dirver's Side Of Roadway. C Lett © Right       Provide Dirver's Side Of Roadway. C Lett © Right       Provide Dirver's Side Of Roadway. C Lett © Right         Row 4:       Image: Dirver's Side Of Roadway. C Lett © Right       Provide Dirver's Side Of Roadway. C Lett © Right       Provide Dirver's Side Of Roadway. C Lett © Right         Row 3:       Image: Dirver's Side Of Roadway. C Lett © Right       Provide Dirver's Side Of Roadway. C Lett © Right       Provide Dirver's Side Of Roadway. C Lett © Right         Row 12:       Type A       35       0       0       240       Provide Dirver's Could Biserver         Row 21:       Type B       37       5       0       0       240       Provide Dirver's Could Biserver         Row 21:       Type B       37       5       0       0       240       Provide Dirver's Could Biserver         Row 21:       Type B       37       5       0       0       240       Provide Dirver's Could Biserver	3 3 (9 9 (9 9) (9 9) (9) (9) (9) (9) (9) (9
0.7       0.7       0.8       0.7       0.6       0.5       0.4       0.5       0.8       1.2       1.5       1.6       1.6       1.0       0.8         0.8       0.7       0.8       0.7       0.5       0.5       0.4       0.6       1.0       1.4       1.7       2.0       1.9       1.2       0.9         0.9       0.7       0.8       0.6       0.5       0.5       0.6       1.2       1.9       1.2       0.9       1.4       1.7       2.0       1.9       1.2       0.9         0.9       0.7       0.8       0.6       0.5       0.5       0.6       1.2       1.9       1.9       2.2       0.9         0.9       0.7       0.6       0.5       0.6       0.7       1.4       2.4       2.2       2.5       2.3       1.4       1.1         0.9       0.7       0.6       0.5       0.6       0.7       1.4       2.4       2.2       2.5       2.3       1.4       1.1         0.9       0.7       0.6       0.5       0.6       0.7       1.4       2.4       2.2       2.5       2.3       1.4       1.1         1.4	>

Figure 2 – Calculate Set Spacing in Roadway Optimizer

### Create additional layouts and compare (Figures 2 & 3):

- 13. Click on the radio button for Layout 2 at the top of the form. All specifics from Layout 1 will be copied to Layout 2. Make any adjustments to Layout 2 and recalculate
- 14. Provided the Roadway configuration and Standard remain the same, the layouts can be compared side by side by selecting the Comparison tab. This is particularly useful when comparing results for different luminaires using the same criteria, or slightly different pole spacings.

	Lav	luc	Comparison
are Layouts: 🔽 1 🛛	2	<b>F</b> 5	(100)
	Layout 1	Layout 2	
escription	Sample layout #1	Sample layout #1	
oadway Standard	IES RP-8-2000	IES RP-8-2000	_
Table	R3	R3	
stual Q0 Value	0.07	0.07	
		40.480.51	_
ayout Type	2H_STD_W/M	2H_STG_W/M	_
oad width	30	30	
idian Width	10	10	_
under Lanes	3	3	_
umber Lanes Opposite	U	0	
rivers Side	Right	Right	_
alc Area	Bottom	Boltom	-
hal David	Y	Turn D	_
soer - now r	1906 0	1300 0	-
H-HOWI	51	31	_
etback · How 1	2	0	-
Otient - How 1	0	0	_
R - How 1	0	0	_
pin - Row 1	0	0	_
pacing - How 1	253	240	_
abal - Dow 2	Tune A	Tune A	-
No non a	1994	26	-
ethank . Perc 2	50	55	-
Origet Days 2	0	0	-
A Pour 2	0	0	-
R - now 2	0	0	-
pering - Rev 2	222	240	-
paying - more 2	6-04	670	-
uminance (Cd/SoM)			
verage	1.01	0.98	
aximum	25	25	
inimum	0.5	0.4	
vo/Min Ratio	2.02	2.45	
as/Min Ratio	5.00	6.25	
ax/Avg Ratio	2.48	2.55	
lum (Fc)			
verage	1.43	1.39	
aximum	3.0	2.9	
initum	0.3	0.2	
vg/Min Ratio	4.77	6.95	
ax/Min Ratio	10.00	14.50	
ax/Avg Ratio	2.1	2.09	
is_Level			
TV	4.2	4.3	
is_Level_Bkgd_Lum (0	2		
verage	1.02	1	
NOTIFIED .	2.5	2.5	

Figure 3 – Optimizer's Compare Tab

### **Output Options for Roadway Optimizer**

Any calculation can be printed with results for each computed metric (i.e. Luminance, Illuminance, etc.) shown on an individual page. The cover page contains details on the photometric files used and luminaire/pole layout. A company logo can be used across the cover page. This output is also easily printed to PDF using any PDF capable printer driver.

Exporting the results from *Roadway Optimizer* into AGi32's Model Mode can be especially useful when the specific calculation should consider additional pole placements aside from the standard roadway. In this case it is easy to drop the output from Roadway Optimizer directly on top of an imported CAD background. Pole placements can be adjusted and amended as required. This is a quick substitute for using the more involved *Calculation Points – Roadway* command discussed in the next section.

## Calculation Points - Roadway command

The *Calculation Points – Roadway* command is available from within the main Model Mode environment of AGi32. Similar to the *Roadway Optimizer*, it performs calculations based on any of the supported international standards. However, in the model environment, the command can be used to place composite roadway calculations<sup>2</sup> in position on top of 2-dimensional CAD created backgrounds considering all luminaires placed within the environment. This provides designers the flexibility to consider any luminaire type and position in the various roadway specific calculations. For example: luminaires can be considered not only along the roadway, but from intersecting roadways, adjacent site lighting, pedestrian lighting or any off-roadway source. Roadway specific calculation point grids can also be stretched across more than one pole cycle to encompass any distance. AGi32 makes every attempt to adhere to the various international standards when grid size exceeds that specified in the standard.

#### Steps to use AGi32's Calculation Points – Roadway command

Each step references Figure 4 below

- 1. Enter a Label and Description for this calculation
- 2. Select the Roadway Standard to be used as the calculation basis
- 3. Enter the number of lanes in the direction of travel
- 4. Select the R-Table to describe the pavement surface characteristics
- 5. Standard calculation metrics for the selected standard are shown on the left. They can be deselected. Specifics associated with each metric will appear in the area on the right.
- 6. Various aesthetic settings can be adjusted if necessary

<sup>&</sup>lt;sup>2</sup> Composite roadway calculations refers to the command capability to place all of the various calculation grids with a single operation: Luminance, Illuminance, Veiling Luminance, Visibility, and more depending on the international standard selected.

Page	6
	-

Figure 4 – The Calculation Points – Roadway dialog

- 7. By clicking OK in the dialog, control is transferred back to the graphics cursor in the Model view. Locate the grid using three points as shown below.
  - a. Point number one (pt1) is on the curb line at the beginning of the analysis zone.
  - b. Point number two (pt2) is on the same curb line at the end of the analysis zone.
  - c. Point number three (pt3) is directly across the roadway from point 2 defining the width of the road in the direction of travel.



Figure 5 – Placing points in Model Mode

The end result can be a series of calculation areas within the project, each in position to analyze the specifics at that location. All luminaires in the project are considered in the final calculation.



Figure 6 – Model Mode with multiple grids

# **Roadway Calculations in 3-dimensional environments**

AGi32 allows 3-dimensional obstructions or reflecting surfaces to be considered in roadway calculations. This is not simply illuminance, but all roadway metrics will consider the shadowing and reflecting properties of objects in the environment. This allows realistic luminance calculations in applications where reflected or obstructed light is a factor such as over/under-passes and tunnels. AGi32 is the only program with this capability.

Starting with the most basic scenario, it is a simple operation to add a roadway surface to a 2-dimensional model to enable AGi32's visualization capability. In the image below we have placed a single polygon object at Z=0 with asphalt reflectance of 10%. The reflectance is actually immaterial at this point as all reflected light is lost without additional surfaces to redirect it back down toward the pavement. It does however, allow a rendered view of the roadway as we now know the diffuse luminance of the pavement surface due to direct light. In terms of the relationship to the actual roadway calculations,

it is set as surface type: "Pavement Surface- Direct Flux Only" using the Surface Edit command and has no impact on the results of this calculation.



Figure 7 – Object added for pavement to facilitate rendering

In a more detailed analysis, an overpass and its obstructive and reflective properties can be considered in the computation of all roadway grids placed in the environment. The critical procedural element within the software is to define all object surfaces as "Roadway Contributors."

Using AGi32's visualization capability it is easy to assess the need for supplemental lighting under the overpass (Figure 8).



Figure 8 – Reflective surfaces (objects) considered in the roadway calculations

## **Roadway Standard Configuration Tool**

There are a number of unique calculations associated with each international roadway standard (North American IES-RP-8-2000, British BSEN 13201-3.2003, European CIE-140-2000, Australian AS1158.2-2005 and New Zealand NZ1158.2-2005). Consider that any software tool must compute a multitude of metrics such as: Illuminance, Pavement Luminance, Veiling Luminance, Visibility Level, Surround Illuminance, Background Luminance, and more for each specific roadway section to be analyzed. Each international standard stipulates similar but different calculations and parameters can vary dramatically.

At Lighting Analysts, we believe we may be the only people that have ever tried to support all of the popular international roadway standards giving us a unique perspective when constructing our new roadway calculation engine. Placing all of the standard calculations in a single software tool begged for underlying code that could handle variations in calculation specifics such that each standard could simply modify a few variables and utilize the same engine. We are proud to have achieved this goal, but perhaps more importantly, we arrived at a landmark decision in the process: Why not

allow individual calculation choices and parameters to be modified on the user level such that an educated party could feasibly construct a completely new standard by mixing calculations from all standards and adjusting specifics? Imagine including the British Semi-cylindrical Illuminance calculation with pavement Luminance calculations from the IES method! How about adjusting the observer position or the grid of calculation points? It can all be done. User modifications can be saved as a custom standard and reused as required in place of published standards.

## Steps to define a custom standard

Steps refer to Figure 9 below

- 1. Select the Create button and provide a name for the standard
- 2. Click the Configure button and select Calculation Metrics to include in the custom standard
- 3. Adjust each metric specifics as necessary by selecting the metric on the left side and editing specifics on the right

Roadway Standards					×
Show Units In:	- Be	loadway Standard			Ok
Meters C Feet	Bo	oadway Standard Custom Research Standard		•	
	Fo	or Single Roadwavs With Two Wav Traffic - Calculation Zone	Acros Covers: C One Direc	tion Only 📀 Entire Roadway	Cancel
	Dr	river's Side Of Boadway (default): (* Loft C. Biokt		Luminaire Cucles	Help
L		inters side of hoddway (deidak). Is Een is hight	(1)	Lanninane eyenee	
Calculation Metrics	Ve Callingu	eiling Luminance	<u> </u>	-Veiling Luminance Formula	Create
Select To Set Metric Spec	Ca	alculation Grid Height Above Roadway		Standard	Delete
Roadway Luminance	of Uma Of	bserver Vertical Line Of Sight 1 Degrees Below H	lorizontal	C CIE-30 (deprecated)	Delete
Semicylindrical Illumin	ance	bserver Age 23		Cite do (deprecated)	
Hemispherical Illumina	ance (3)	dsheild Cutoff Angle 20 Degrees Above H	lorizontal (90 = No Cutoff)		
Veiling Luminance	<b>_</b>	amp Conditions:  Initial C Maintained  Normalize	Per 1000 Lumens		
Paadway Standard Calculation Mat	rice 🔽		ar er rood Lumens		
Roadway Standard - Calculation Met		Calculation Grid	Obs	erver(s)	
Calculation Metrics Check all Calculation Metrics to include	Ok	Point Spacing Across Roadway (Rows	Point Spacing Along Roadwa	av (Columns)	
in this standard:	Cancel	C Set Spacing	C Set Spacing 0		
Roadway Luminance		First Row Offset: Minimum 0.25 x Spc.	First Column Offset: Minim	num 0.25 x Spc.	
Longitudinal Uniformity (Lum)	Help	Maximum 0.75 × Spc	Maxir	mum 0.75 x Spc.	
Vertical Illuminance		Jaro Jaro		10.70	
Semicylindrical Illuminance	1	Number Of Rows: C Per Roadway  Per Lane	Number Of Columns Pe	r Luminaire Cycle	
Hemispherical Illuminance		Consider One Lane Only (Per Observer)	Minimum Number Of Points	s 10	
Visibility Level (STV)		Static - Number Of Rows	Maximum Allowable Spacin	ng 3	
✓ Veiling Luminance		Row Offset* Adder	First Column Offset	0.5 x Spc.	
		▶ Row 1 0.5 0			
		Actual Distance = Offset v Boad or Lane Width			
		Minimum Number Of Points			
	(2)	Maximum Allowable Senseing			
	$\mathbf{Y}$	Maximum Autowalie Spacing			
1		First How Uffset 0.5 x Spc.			
	Configure			Apply To All Metrics	

Figure 9 – The Roadway Standard Configuration Tool

This is the birth of the *Roadway Standard Configuration Tool* - what we hope will become an indispensable research aid for roadway specialists everywhere!